

112-02-GL
FLOWMETER CALIBRATION DATA
112/6

CUSTOMER	CUST. P.O. No	REF. CURVE NUMBER
		0587-A1-AM-07N

Max. Flow	Min. Flow	Units	Metering Fluid	Date
5.50	0.225	std. ml/min	water	30-Nov-1999

Model Number		Metering Temperature	70.0 °F
Tube Number	112-02-GL	Metering Pressure	14.70 psia
Serial Number		Metering density	1.000 g/ml
Float Material	glass	Metering Viscosity	1.000 cp
Float Density	2.53 g/ml	Density at STD.Cond	1.000 g/ml
STD. Conditions	STP: 1 atm @ 70 °	Accuracy	std.
Room Temperature	70.0 °F	Barometric Pressure	14.70 psia

SCALE READINGS AT CENTER OF FLOAT	
Scale Reading (mm)	Flow
150	5.50
140	4.70
130	4.24
120	3.71
110	3.20
100	2.74
90	2.31
80	1.88
70	1.55
60	1.24
50	0.950
40	0.690
30	0.490
20	0.325
10	0.225

