



Model 052

Cable

Installation and Operating Manual

**For assistance with the operation of this product,
contact PCB Piezotronics, Inc.**

**Toll-free: 800-828-8840
24-hour SensorLine: 716-684-0001
Fax: 716-684-0987
E-mail: info@pcb.com
Web: www.pcb.com**



The information contained in this document supersedes all similar information that may be found elsewhere in this manual.

Total Customer Satisfaction – PCB Piezotronics guarantees Total Customer Satisfaction. If, at any time, for any reason, you are not completely satisfied with any PCB product, PCB will repair, replace, or exchange it at no charge. You may also choose to have your purchase price refunded in lieu of the repair, replacement, or exchange of the product.

Service – Due to the sophisticated nature of the sensors and associated instrumentation provided by PCB Piezotronics, user servicing or repair is not recommended and, if attempted, may void the factory warranty. Routine maintenance, such as the cleaning of electrical connectors, housings, and mounting surfaces with solutions and techniques that will not harm the physical material of construction, is acceptable. Caution should be observed to insure that liquids are not permitted to migrate into devices that are not hermetically sealed. Such devices should only be wiped with a dampened cloth and never submerged or have liquids poured upon them.

Repair – In the event that equipment becomes damaged or ceases to operate, arrangements should be made to return the equipment to PCB Piezotronics for repair. User servicing or repair is not recommended and, if attempted, may void the factory warranty.

Calibration – Routine calibration of sensors and associated instrumentation is

recommended as this helps build confidence in measurement accuracy and acquired data. Equipment calibration cycles are typically established by the users own quality regimen. When in doubt about a calibration cycle, a good “rule of thumb” is to recalibrate on an annual basis. It is also good practice to recalibrate after exposure to any severe temperature extreme, shock, load, or other environmental influence, or prior to any critical test.

PCB Piezotronics maintains an ISO-9001 certified metrology laboratory and offers calibration services, which are accredited by A2LA to ISO/IEC 17025, with full traceability to N.I.S.T. In addition to the normally supplied calibration, special testing is also available, such as: sensitivity at elevated or cryogenic temperatures, phase response, extended high or low frequency response, extended range, leak testing, hydrostatic pressure testing, and others. For information on standard recalibration services or special testing, contact your local PCB Piezotronics distributor, sales representative, or factory customer service representative.

Returning Equipment – *Following these procedures will insure that your returned materials are handled in the most expedient manner.* Before returning any equipment to PCB Piezotronics, contact your local distributor, sales representative, or factory customer service representative to obtain a Return

Materials Authorization (RMA) Number. This RMA number should be clearly marked on the outside of all package(s) and on the packing list(s) accompanying the shipment. A detailed account of the nature of the problem(s) being experienced with the equipment should also be included inside the package(s) containing any returned materials.

A Purchase Order, included with the returned materials, will expedite the turn-around of serviced equipment. It is recommended to include authorization on the Purchase Order for PCB to proceed with any repairs, as long as they do not exceed 50% of the replacement cost of the returned item(s). PCB will provide a price quotation or replacement recommendation for any item whose repair costs would exceed 50% of replacement cost, or any item that is not economically feasible to repair. For routine calibration services, the Purchase Order should include authorization to proceed and return at current pricing, which can be obtained from a factory customer service representative.

Warranty – All equipment and repair services provided by PCB Piezotronics, Inc. are covered by a limited warranty against defective material and workmanship for a period of one year from date of original purchase. Contact

PCB for a complete statement of our warranty. Expendable items, such as batteries and mounting hardware, are not covered by warranty. Mechanical damage to equipment due to improper use is not covered by warranty. Electronic circuitry failure caused by the introduction of unregulated or improper excitation power or electrostatic discharge is not covered by warranty.

Contact Information – International customers should direct all inquiries to their local distributor or sales office. A complete list of distributors and offices can be found at www.pcb.com. Customers within the United States may contact their local sales representative or a factory customer service representative. A complete list of sales representatives can be found at www.pcb.com. Toll-free telephone numbers for a factory customer service representative, in the division responsible for this product, can be found on the title page at the front of this manual. Our ship to address and general contact numbers are:

PCB Piezotronics, Inc.
3425 Walden Ave.
Depew, NY 14043 USA
Toll-free: (800) 828-8840
24-hour SensorLineSM: (716) 684-0001
Website: www.pcb.com
E-mail: info@pcb.com

Model Number
052

2 CONDUCTOR + DRAIN WIRE, SHIELDED CABLE

Revision: C
ECN #: 27484

Performance

Number of Conductors
Cable Style
Cable Configuration
Environmental
Temperature Range
Electrical

Resistance
Capacitance(conductor to conductor @ 70 °F (21 °C))
Inductance
Voltage Rating(rms - maximum)

Physical

Cable Jacket Diameter(± .010 in)
Cable Jacket Material
Cable Jacket Color
Conductor Style

Conductor Material
Conductor Diameter(20 AWG)
Insulation Material Over Conductor(s)
Shield Type Over Bundle

Shield Material Over Bundle
Drain Wire Material
Filler Material
Bend Radius(minimum)
Weight

All specifications are at room temperature unless otherwise specified.
In the interest of constant product improvement, we reserve the right to change specifications without notice.
ICP® is a registered trademark of PCB Group, Inc.

ENGLISH

2
Multi Conductor - Shielded
Twisted Pair

-58 to +250 °F
<10 ohms/1000 ft
36 pF/ft
0.34 µH/ft
600 V

0.25 in
Polyurethane
Black
Stranded - 19 strands 32
AWG

Tin Plated Copper
0.04 in
FEP Teflon
Braid: 90% Minimum
Coverage

Tin Plated Copper
Tin Plated Copper
Kevlar Tie Cord
2.5 in
0.67 oz/ft

SI

2
Multi Conductor - Shielded
Twisted Pair

-50 to +121 °C
<33 ohms/km
118 pF/m
1.12 µH/m
600 V

6.35 mm
Polyurethane
Black
Stranded - 19 strands 32
AWG

Tin Plated Copper
1.02 mm
FEP Teflon
Braid: 90% Minimum
Coverage

Tin Plated Copper
Tin Plated Copper
Kevlar Tie Cord
63.5 mm
61.85 gm/m

NOTES:
[1] Typical.

OPTIONAL VERSIONS

Optional versions have identical specifications and accessories as listed for the standard model except where noted below. More than one option may be used.

Entered: <i>SLH</i>	Engineer: <i>MLM</i>	Sales: <i>SG</i>	Approved: <i>MF</i>	Spec Number:
Date: 10-11-07	Date: 10-9-07	Date: 10-10-07	Date: 10-10-07	31853



IMI SENSORS
3425 Walden
Depew, NY 14043
UNITED STATES
Phone: 800-959-4464
Fax: 716-684-3823
E-Mail: imi@pcb.com
Web site: http://www.imi-sensors.com