

Product datasheet

uvex 3 6874 1-3

Safety boot DIN EN ISO 20345:2022+A1:2024 S3L FO CI SC SR

Sizes: 36 - 52 | Width: 10, 11, 12



AREA OF APPLICATION

Heavy-duty applications place extensive demands on the safety shoe, its durability and stability due to external influences.

OUTSOLE

Dual-density polyurethane sole



- shock-absorbing and energy-returning uvex i-PUREnrj planet midsole with 10% recycled granulate from residues
- **bionom x** – ergonomically designed PU outsole
- antistatic
- short-term heat-resistant up to 120°C
- cold-insulating (**CI**)
- excellent slip resistance (**SR**)
- oil- and fuel resistant (**FO**)
- free of silicones, plasticisers and other substances that interfere with wetting agents



FEATURES

Upper material	• hydrophobic leather (uvex waterstop technology) • water-repellent (WPA)
Lining material	• textile distance mesh lining for comfortable foot climate (clima zone)
Fastening	• laces
Heel basket	• foamed heel basket out of PU for additional stability in the shoe
Reflecting elements	• for increased visibility even in dark working environments
Comfort	• soft padding on collar • sizes 36-40 have been produced using a women's last • dust tongue • uvex lacelock fastening hook • removable comfortable innersole
Innersole	

PROTECTIVE FEATURES

Toe cap	• metal-free protective toe cap
Penetration resistance	• metal-free, textile penetration resistance
Scuffcap	• out of PU for additional protection of the upper material (SC)
Ankle protection	• uvex anklepro to protect against impacts

CERTIFICATES

uvex medicare+	• certified for orthopaedic innersoles and shoe adjustments according to the description in DGUV 112-191
ESD	• protection against electrostatic charge according to EN 61340-4-3 und EN 61340-5-1

SUSTAINABILITY

Recycled/sustainable materials	• midsole and removable innersole made wholly or partly from recycled materials • free from harmful substances in accordance with the uvex restricted substances list
--------------------------------	--

ACCESSORIES/ SPARE PARTS

Replacement innersole	• 8693 7-9
Laces	• black 9599922