
Full Face Mask BRK 820

Safety with perspective



1-300 EN 05/2005



**BARTELS
+ RIEGER**

ATEMSCHUTZTECHNIK · ARBEITSSCHUTZ

Full Face Mask BRK 820 Safety with perspective.....

The BRK 820 full face mask is tested to EN 136, class 3, certified to PPE-Directive 89/686/EEC and carries the CE-mark. Safety, comfort and easy maintenance stand for this construction.

Versatility ...

Ideal face piece for the following areas of use

- Industry
- Agriculture
- Rescue services
- Handling of dangerous goods

There are three types available

- Negative pressure type with a standard thread connector to EN 148-1 (Rd 40 x 1/7").
- Unique Positive pressure type with a standard thread to EN 148-3 (M 45x3).
- Combined negative and positive pressure type with standard thread to 148-1 and snap in connector for demand valves.

High visibility ...

- Low positioning of the connector group with it's two parallel exhalation valves gives a maximum field of vision.
- A heat resistant polycarbonate visor, scratch proofed, approved for fire brigade use, is fitted as standard.
- Guaranteed fog free vision.

High degree of comfort and safety...

- 5-point-harness, easy to use and functional design.
- The design of the seal makes it suitable for every shape of head.
- An integrated shock absorber is fitted to the connector to prevent possible impact injury.
- A robust speech diaphragm of polyester in a stainless steel housing.
- Variable fixing possibilities for the carrying strap.
- Face piece made of a smooth rubber mixture or as option of yellow silicone which is not allergenic.

Maintenance advantages

- no special tools necessary
- all screws protected against falling out
- easy handling for exchange of gaskets and valve membranes

Type variations

Full face mask BRK 820

of black rubber mixture with heat resistant polycarbonate (PC) visor

Art.-No. 111200

Full face mask BRK 820 V

of black rubber mixture with laminated glass visor, (heat- and solvent-resistant)

Art.-No. 111201

Full face mask BRK 820 G

of black rubber mixture with hard coated PC visor, (scratch-proof, heat- and solvent-resistant)

Art.-No. 111208

Full face mask BRK 820 SG

of yellow silicone with hard coated PC visor

Art.-No. 111209

Full face mask BRK 820 SV

of yellow silicone with laminated glass visor

Art.-No. 111203



Full face mask BRK 820 SV