

Lovibond® Water Testing

Tintometer® Group



MD 100 Chlorine, pH, Cyanuric acid, Alkalinity-m, liquid reagents for Chlorine and pH (OTZ)

Precise Water Analysis in High-Quality Design



- Lightweight, rugged design for use in the field
- Single unit construction with no parts to lose or break
- Large, easy to read display
- Industry specific parameter combinations available

Part Number: 278075

The MD 100 has several key features that make it a favorite among users.

Waterproof Design

The IP 68 design of this instrument ensures that the MD 100 remains water tight for up to 1 hour at 0.1 meter. Don't worry about dropping the instrument into a body of water - it floats!

Accurate, Reproducible Results

The optical system of the MD 100 utilizes LEDs and interference filters which quickly gives you results that you can be confident in.

User Calibration Mode

A one-point calibration is possible. Additionally, all MD 100 instruments have the ability to display readings directly in ABS or %T units.

One-time-Zero Function

Don't waste time waiting for your instrument to Zero after each test.

When testing a new sample, zero the instrument once and all subsequent tests of that sample do not require you to re-zero the instrument.

Automatic Data Storage with Transfer Capabilities

The MD 100 automatically stores the last 16 readings with time and date stamp. These results can be transferred to a spreadsheet using the IRiM accessory.

Ergonomic Design

Whether you're using the MD 100 out in the field or in the lab, the design of the instrument makes it easy to handle and view the display. If you're using the instrument in the lab, the rubber feet on the bottom of the housing eliminates the need for two hand operation or to chase your instrument around the workbench.

Factory Programmed

All MD 100 instruments are supplied ready to use with up to 14 calibration curves. All you need to do is select the test you need, prepare your sample and test!

Scroll Driven Menu System

The simple interface allows you to quickly reach the test you need. When the instrument is turned on, it will automatically display the last test used.

2-Year Manufacturer's Warranty

Industry

Marine Industry | Municipalities | Pool Public | Pool Services

MD 100 Chlorine, pH, Cyanuric acid, Alkalinity-m, liquid reagents for Chlorine and pH (OTZ)

The Lovibond® MD 100 4in1 Pool Photometer is a multi-parameter instrument which allows for fast and easy measurement of pool water quality. Three parameters can be measured utilizing tablet reagents, pH is measured using a liquid reagent. Ideal for poolside testing, the MD 100 comes ready to use with all of the reagents and accessories required for testing.

Measuring Range

Test Name	Measuring Range	Chemical Method
Alkalinity-m T	5 - 200 mg/L CaCO ₃	Acid / Indicator
Chlorine HR T	0.1 - 10 mg/L Cl ₂ ^{a)}	DPD
Chlorine L	0.02 - 4.0 mg/L Cl ₂ ^{a)}	DPD
Chlorine T	0.01 - 6.0 mg/L Cl ₂ ^{a)}	DPD
CyA T	10 - 160 mg/L CyA	Melamine
pH value L	6.5 - 8.4 pH	Phenol Red
pH-value T	6.5 - 8.4 pH	Phenol Red

Technical Data

Optics	LEDs, interference filters (IF) and photo sensor in transparent sample chamber. Depending on the version, up to 3 different interference filters are used. Wavelength specifications of interference filters: 430 nm Δλ = 5 nm 530 nm Δλ = 5 nm 560 nm Δλ = 5 nm 580 nm Δλ = 5 nm 610 nm Δλ = 6 nm 660 nm Δλ = 5 nm
Wavelength Accuracy	± 1
Photometric Range	-2500 - 2500 mAbs
Display	backlit LCD (on keypress)
Interfaces	Infrared
Operation	Foil keypad
Calibration	factory calibration and user calibration. Reset to factory calibration possible
Internal Storage	internal ring memory for 16 data sets
Battery Life Time	approx. 17 hours
Clock	Real Time Clock and Date
Portability	Portable
Compliance	CE
Dimensions	6.1 x 2.95 x 1.38"

Delivery Scope

- Instrument in plastic case
- DPD 1 Buffer Solution
- DPD 1 Reagent Solution
- DPD 3 Solution
- Phenol Red Solution
- 100 tablet reagents CyA-Test
- 100 tablet reagents Alka-M Photometer
- 4 micro batteries (AAA)
- 3 round cuvettes (glass) with lid
- Sealing rings
- Stirring rod
- Brush
- Instruction manual
- Quick Start Guide
- Certificate (COC)
- Warranty information

Title	Part Number
Water Sampler & 250 mL Bottle	170500
Micro batteries (AAA), set of 4	1950026
Multy cuvette-2, set of 12	197600
Round cuvette 24 mm ø, set of 12	197620
Sealing ring for round vials 24 mm ø, set of 12	197626
Round cuvette 24 mm ø, set of 5	197629
Cleaning cloth	197635
Round cuvette 16 mm ø, set of 10	197665
Adapter for round cuvettes 16 mm ø	19802190
Mixing cylinder, 25 ml	19802650
Verification Standard Kit MD 100 / 200	215670
Reference Standard Kit Chlorine - 0.2 and 1.0 mg/l (MD 100/110/200)	275650
Reference Standard Kit Chlorine - 0.5 and 2.0 mg/l (MD 100/110/200)	275655
Reference Standard Kit Chlorine - 1.0 and 4.0 mg/l (MD 100/110/200)	275656
Reference Standard Kit pH - 7.45 (MD 100/110/200)	275670
Stirring rod, 13 cm length	364100
Stirring rod, 10 cm length	364109
Box with 10 plastic stirring rods	364120
Box with 10 plastic stirring rods	364130
Membrane filter set for use when preparing samples, 25 membrane filters 0.45 µm, 2 syringes 20 ml	366150
250 mL bottle with cap	375072
Brush, 11 cm length	380230
Measuring beaker, 100ml	384801
Cuvette stand for 6 round cuvettes Ø 24 mm	418951
Cuvette stand for 10 round cuvettes Ø 16 mm	418957
Plastic funnel with handle (white)	471007
ValidCheck Chlorine 1,5 mg/l	48105510
Additionally for each method	999855

Tintometer GmbH

Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
sales@lovibond.com
www.lovibond.com
Germany

The Tintometer Limited

Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
sales@lovibond.uk
www.lovibond.com
UK

Tintometer China

9F, SOHO II C. No.9 Guanghualu,
Chaoyang District,
Beijing, 100020
Customer Care Tel.: +86 (021) 69910081
Tel.: +86 10 85251111 Ext. 330
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Lovibond Tintometer Sdn Bhd

Unit B-3-12, BBT One Boulevard,
Lebuh Batu Nilam 2, Bdr Bkt Tinggi,
41200, Klang, Selangor,
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malaysia

Tintometer Brazil

Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@lovibond.us
www.lovibond.com.br
Brazil

Tintometer Inc.

6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@lovibond.us
www.lovibond.us
USA

Tintometer India Pvt. Ltd.

Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@lovibond.in
www.lovibondwater.in
India

Tintometer Spain

Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Spain