

Dräger X-plore® 3300/3500 Half Masks

Experience a new dimension of comfort and safety in respiratory protection: Dräger has worked together with users from industry and the skilled professions to develop a new line of twinfilter respirators. It very successfully combines practicality of use with comfort. The use of new materials coupled with a modern, attractive design guarantees maximum comfort and user acceptance.



ST-12949-2007

Wherever respiratory protection is needed, e.g. at chemical and steel plants, auto-mobile and shipping industry, maintenance, utilities supply and disposal, Dräger X-plore half masks can provide you a perfect solution.

Choose from either the low maintenance, economical Dräger X-plore 3300 version or the very comfortable and robust Dräger X-plore 3500 version for long-term, demanding tasks.

Major features include the "FlexiFit" head cradle, almost unnoticeable under a safety

helmet. The innovative X-guided strap-system distributes weight evenly and the "swept-back" design allows for a perfect fit underwelding shields and visors.

Dräger X-plore half masks are available in three sizes, ensuring a great fit for different face types. Equipped with a safe and easy to use bayonet connection they are compatible with the extensive Dräger X-plore filter range.

Discover the benefits of Dräger X-plore for yourself.

FEATURES & BENEFITS

Easy and safe handling	High level of user safety.
"FlexiFit" head cradle	The new head cradle provides an excellent fit for any head, also under safety helmets.
"Low profile" design	The swept-back design ensures an optimal field of vision and fits well under protective visors.
Strap System	Innovative X-guided strap system ensures an even weight distribution. Easy to adjust for a perfect fit.
Flexible nose section	Gives more secure seal in the most critical area. Great compatibility with safety glasses and goggles.
Bayonet connector	Easy and secure filter attachment. Both filters are inserted in a top-down direction.

Special for Dräger X-plore® 3500:

New material	Mask body made of "DrägerFlex" material: hypoallergenic, extremely comfortable, and excellent resistance.
"Drop Down" harness	By undoing the neck hook, the mask can be removed without removing e.g. a safety helmet. The inner mask faces the body and remains protected.



ST-5468-2007

Dräger X-plore® 3300

The low maintenance, economical half mask.



ST-718-2006

Dräger X-plore® 3500

The very comfortable and robust half mask for long-term demanding tasks.



ST-12430-2008

Dräger X-plore® Painter Set:

Dräger X-plore® 3300 (size M)
+ 2 filters A2 P3 R D

TECHNICAL DATA

Material of mask body	Dräger X-plore® 3300: Soft-TPE – friendly to the skin, comfortable to wear, lightweight, translucent grey Dräger X-plore® 3500: "DrägerFlex" – very friendly to the skin, hypoallergenic, extremely comfortable, robust, black
3 sizes	small (S), medium (M), large (L)
Filter connection	Two side-positioned bayonet connectors for use with the Dräger X-plore® filter range
Weight	approx. 95 g
Approvals	CE-certified (EN 140), Australian Standard AS/NZS 1716, NIOSH 42 CFR 84
Maintenance	Spare parts available for Dräger X-plore® 3500
Extras	Drop down harness system and resealable storage bag (with Dräger X-plore® 3500)

ORDERLIST

Dräger X-plore® 3300 half mask	Small	R 55 331
	Medium	R 55 330
	Large	R 55 332
Dräger X-plore® 3500 half mask (with drop down harness and storage bag)	Small	R 55 351
	Medium	R 55 350
	Large	R 55 352
Sets:	Painter Set (Dräger X-plore® 3300 (size M) + 2 filters A2 P3 R D)	R 57 793
	Chemical Works Set (Dräger X-plore® 3300 (size M) + 2 filters A1B1E1K1 Hg P3 R D)	R 57 794
	Construction Set (Dräger X-plore® 3500 (size M) + 2 filters Pure P3 R)	R 56 960
Accessories:	Bayonet Test Plug (for Pressure Drop Testing)	AG 02 460
	Portacount T [®] est Adaptor Set	67 38 044
	Carrying Box "Wikru"	RM 07 000

The Dräger X-plore filter series offers an extensive range of particle, gas & vapour, and combination filters and cartridges (see separate data sheet).

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany

www.draeger.com

AUSTRALIA

Draeger Safety Pacific Pty. Ltd.
8 Acacia Place
Notting Hill VIC 3168
Toll-free +61 1800 DRAGER
(1800 372 437)
Fax +61 1800 64 74 84
customer.service@draeger.com

CANADA

Draeger Safety Canada Ltd.
7555 Danbro Crescent
Mississauga, Ontario L5N 6P9
Tel +1 905 821 8988
Fax +1 905 821 2565

P. R. CHINA

Draeger Safety Equipment
(China) Co., Ltd.
A22 Yu An Rd, B Area,
Tianzhu Airport Industrial Zone,
Shunyi District, Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

FRANCE

Draeger Safety France SAS
3c route de la Fédération, BP 80141
67025 Strasbourg Cedex 1
Tel +33 3 88 40 76 76
Fax +33 3 88 40 76 67

MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5 Bodega No. 37
Fraccionamiento Industrial
San Pedrito
Querétaro, Qro México
Tel +52 442 246-1113
Fax +52 442 246-1114

NETHERLANDS

Dräger Safety Nederland B.V.

Edisonstraat 53
2700 AH Zoetermeer
Tel +31 79 344 46 66
Fax +31 79 344 47 90

REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd.
67 Ayer Rajah Crescent
#06-03
Singapore 139950
Tel +65 68 72 92 88
Fax +65 65 12 19 08

REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.
Complejo Business Park,
V tower, 10th floor
Panama City
Tel +507 377-9100
Fax +507 377-9130
contactcsa@draeger.com

REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

SPAIN

Dräger Safety Hispania S.A.
Calle Xaudaró 5
28034 Madrid
Tel +34 91 728 34 00
Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside
Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352-891
Fax +44 1670 356-266

USA

Draeger Safety, Inc.
101 Technology Drive
Pittsburgh, PA 15275
Tel +1 412 787 8383
Fax +1 412 787 2207

Manufacturer:

Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany