



Order no.: 422 791

EAN: 4013207422748

Product designation:

GAS FILTER DIRIN 230 AX

In connection with full face masks (EN 136) and half masks (EN 140) with round thread connection (EN 148-1). Protection against low-boiling (<65°C) organic gases and vapours



DESCRIPTION

The filter case is round and consists of filter pot and filter lid. The filter pot contains the round thread connection according to EN 148-1; the filter lid is open to the inhalation side. There is a filter bed with activated charcoal. This is firmly fixed by the filter case and internal screens. Both filter openings are locked by water-vapour-proof cover caps

MATERIALS

All used materials are incinerated

- Filter case: Plastic (ABS)
- Sorbents: Impregnated active charcoal
- Cover cap: Plastic
- Banderole: Paper

WEIGHT

- approx. 199 g

MAIN FEATURES

By addition to sorbent (Impregnated active charcoal), the gases and vapours will be removed from the ambient air

- **Inhalation resistance:** at 30 l/min, constant flow max. 1.4 mbar (according to EN 14387)
at 95 l/min, constant flow max. 5.6 mbar (according to EN 14387)

MARKING

- Trade mark of manufacturer (LOGO)
- Product designation
- Applied standard
- Consider the information brochure
- Expiry of shelf-life (MM/YYYY)
- Lot-No.(PARTITA)
- CE-Identification
- PNotified body
- Identification color: brown

DONNING AND USING

- Open the Filter (Remove the cover caps) and screw the Filter firmly into the facepiece connector directly before use
- Use the Filter in accordance with the information brochure

STORAGE CONDITIONS

- Ambient temperature. Protect against cold, heat and humidity
- Consider conditions noted on the packaging

WARNING REFERENCE

- Use in accordance with the requirements only!

CERTIFICATIONS

- The Filter is certified according to EN 14387
- Certified according to European Regulation (EU) 2016/425

USER REFERENCES

EKASTU Safety GmbH guarantees the indicated achievement according to class and type. It is to be noted that the laboratory test values can considerably deviate from those, which are reached in practice. The user must read and understand all functional information. Use the Respiratory protective devices with this information brochure, the relevant valid statutory regulations and the safety requirements of the profession associations, particularly the regulations for use in accordance with DGUV Rule 112-190 resp. DIN EN 529 'Respiratory protective devices – recommendation for selection, use, care and maintenance – guidelines'.

TD 422 791 English_01-03.25