

# IQ SENSOR NET Sensors



## SensoLyt® pH/ORP

- SensCheck function monitors sensors
- electrodes are protected
- easily replace electrodes without tools as needed
- pre-amplified sensors
- integral temperature sensor
- digital sensors store calibration
- 2-year warranty (6-months electrodes)

### SensoLyt® Sensor

<b>Operating Temperature</b>	32 to 140°F (0 to 60°C)			
<b>Electrode Type</b>	SEA and SEA-HP pH (gel-polymer solid electrolyte with double pinhole diaphragm; AgCl free and resistant to sulfides)	DWA pH (modified gel electrolyte with single pinhole diaphragm)	ECA pH (gel electrolyte with single pinhole diaphragm)	PtA mV (gel-polymer solid electrolyte with double pinhole diaphragm)
<b>Range</b>	2 to 12 pH units and 4 to 12 pH units	0 to 14 pH units	2 to 12 pH units	± 2000 mV (depends on terminal)