



The portable Lab

pHotoFlex® COLORIMETER - FIELD SET FOR WATER MONITORING

- Standardized and easy-to-use
- Sturdy and waterproof
- Sophisticated and versatile



a xylem brand

The portable Lab: pHotoFlex® Colorimeters in Field Sets

Safe "Outdoor" Handling:

- Lab Tray - a small removable table with cavities
- Tidy up: Pipettes, vials, accessories, ...
- Waterproof short instruction including program list
- Storage with Identification (ID) number, e.g. for location
- Convenient data management



A Strong Team: pHotoFlex® & small sized Powder Pillow Test Kits

These small reagent portions in sachets can be dosed directly into the sample, which minimizes pipetting: ideal for field monitoring and for special situations such as flooding.

pHotoFlex® Field Set Overview

SERIES pHoto Flex	STD	pH	TURB
Portable Colorimeter with 6 wavelength			
pH Measurement (± 0.01 pH, ATC)/ORP	-	●	●
Turbidity Measurement IR acc. DIN/ISO	-	-	●
Special programs for NH ₃ , CO ₂ with pH and temp dependent	-	●	●
Integrated lab table supporting outdoor use	Work bench with cavities for stable stand of vials, electrode, beakers etc.		
pH electrode SenTix® 41 with stand	-		●
Technical Buffers 7.00 and 4.01	-		●
KCl 50 ml	-		●
Pipetting	2x2 ml + 10 ml scaled syringes	0,500 - 5,000 ml variable piston pipette	
Calibration Standards Turbidity 0.02-10-1000 NTU AMCO Clear®	-	-	●
Accessories	Zero Cell 16 mm, waterproof short instruction including programmed test kits, cleaning tissues, LSdata PC software for convenient and GLP data handling, PC connecting cable AK 540/B, screw driver, beaker 50 ml, 5 vials 28 mm, 4 batteries (AA), documentation		
Waterproof Housing	IP 67		
Certificates	CE/ETLus/cETL		
AQA	pHotoFlex® Check, Calibration interval setting und records (pH, turbidity)		

Ordering Information

Model	Description	Order No.	Price*
pHotoFlex® STD SET	pHotoFlex® STD Field Set	251 205	1,795.00
pHotoFlex® pH SET	pHotoFlex® pH Field Set	251 200	2,470.00
pHotoFlex® Turb SET	pHotoFlex® Turb Field Set	251 210	2,910.00

*all prices without local taxes.

For more detailed information please order free of charge our catalog **"Lab and Field Instrumentation"** or visit our web site: www.wtw.de/en/photoflex (For convenience use our QR code).



WTW Wissenschaftlich-Technische Werkstätten GmbH · Dr.-Karl-Slevogt-Straße 1 · D-82362 Weilheim, Germany
Phone: +49 881 183-0 · Fax: +49 881 183-420 · E-Mail: Info.WTW@XylemInc.com · www.wtw.com

All names are registered trademarks or trademarks of Xylem Inc. or one of its subsidiaries. Technical changes reserved.
© 2014 WTW GmbH. 999136US June 2014

