

Dräger X-plore® 6300 Full Face Mask

The Dräger X-plore® 6300 is the efficient yet low-cost full face breathing mask intended for price-conscious users not wishing to compromise on comfort or quality. This full face mask is the successor to the Panorama Nova Standard, a mask which has proven itself over decades of use worldwide – redesigned and improved with fresh colours and an integrated bar code.



The Dräger X-plore® 6300 is designed for use by professionals in industry, and meets the highest demands for reliability, fit and comfort. Together with the respiratory filters from Dräger's comprehensive X-plore® Rd40 filter range, it has proven suitable for a wide range of different applications. For longer application periods this mask can be used together with the Dräger powered air purifying respirators (e.g. X-plore® 7300 or 7500 series).

The mask body, which is made of robust and hypoallergenic EPDM, features a double-layer face seal with triple sealing action for a secure and comfortable fit on just about any shape of face. The mask comes in a universal "one size fits all", making logistics and storage easy. The comfortable five-point head harness not

only ensures that the mask can be donned easily and quickly, but is wide enough to prevent any pressure points on the wearer's head. The scratch-proof and distortion-free PMMA Plexiglas visor with 180° wide-angle guarantees a large field of vision with panoramic view. The robust frame is made of extra-light plastic, and the intelligent ventilation system ensures that the visor remains fog-free.

A barcode inside the mask makes checking inventories and carrying out mask maintenance easy. Valves can even be serviced without tools. A full range of accessories and spare parts are available. High quality materials and careful workmanship ensure mask longevity, making the masks highly cost effective.



Dräger X-plore® 6300 EPDM/PMMA

TECHNICAL DATA

Mask body	Highly resistant and hypoallergenic EPDM
Visor	Scratch-proof PMMA (Plexiglas) with 180° wide-angle
Connector	Sturdy plastic with inhalation and exhalation valve, standard thread connection Rd 40x1/7" as per EN 148-1
Weight	Approx. 500 g
Tested and approved	EN 136 Class 2 (CE mark), NIOSH, AS/NZS

ORDER INFORMATION

Description		Order no.
Dräger X-plore® 6300 EPDM/PMMA	with PMMA lens and plastic frame	R 55 800
Accessories		
Wikov V carrying box		R 51 019
Mask spectacles frame		R 51 548
Anti-fogging gel "klar-pilot" (50 ml)		R 52 560
DAISYquick cleaning cloths (pack of 10)		R 54 134
Welding shield		40 53 437
Adapter for welding shield	for supplementary panels and welding protective filters with a 110mm x 90mm format	R 57 308

The compatible Dräger X-plore® Rd40 (RA) filter series with standard thread connection as per EN 148-1 includes an extensive range of different particle, gas and combination filters (see separate data sheet Dräger X-plore® Rd40 Filters for further details).

HEADQUARTERS

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES

AUSTRALIA

Draeger Safety Pacific
Pty. Ltd.
Axxess Corporate Park
Unit 99, 45 Gilby Road
Mt. Waverley. Vic 3149
Tel +61 3 92 65 50 00
Fax +61 3 92 65 50 95

CANADA

Draeger Canada Ltd.
7555 Danbro Crescent
Mississauga,
Ontario L5N 6P9
Tel +1 905 821 89 88
Fax +1 905 821 25 65

P. R. CHINA

Beijing Fortune Draeger Safety
Equipment Co., Ltd.
A22 Yu An Rd, B Area,
Tianzhu Airport Industrial Zone
Shunyi District,
Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

FRANCE

Dräger Safety France SAS
3c route de la Fédération
BP 80141
67025 Strasbourg Cedex 1
Tel +33 3 88 40 59 29
Fax +33 3 88 40 76 67

NETHERLANDS

Dräger Safety Nederland B.V.
Edisonstraat 53
2700 AH Zoetermeer
Tel +31 79 344 46 66
Fax +31 79 344 47 90

MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5
Bodega No. 37
Fraccionamiento Industrial
San Pedrito, Querétaro
Qro México
Tel +52 442 246-1113
Fax +52 442 246-1114

SINGAPORE

Draeger Safety Asia Pte Ltd
67 Ayer Rajah
Crescent #06-03
Singapore 139950
Tel +65 68 72 92 88
Fax +65 65 12 19 08

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd.
P.O.Box 68601
Bryanston 2021
Tel +27 11 465 99 59
Fax +27 11 465 69 53

SPAIN

Draeger Safety
Hispania S.A.
Calle Xaudaró 5
28034 Madrid
Tel +34 91 728 34 00
Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside
Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352 891
Fax +44 1670 356 266

USA

Draeger Safety, Inc.
101 Technology Drive
Pittsburgh, PA 15275
Tel +1 412 787 83 83
Fax +1 412 787 22 07