

Lovibond® Water Testing

Tintometer® Group



SD20 ORP



- Transparent lid for easy maintenance and storage
- Ideal lid design for a stable stand
- Display colours & symbols for easy use
- New multi-parameter models for individual measurement requirements

Part Number: 720020

Industry

Industries Others | Marine Industry | Municipalities | Pool Public | Pool Services

SD20 ORP

With its waterproof housing, the Pocket Tester is ideal for regular checks in industrial plants or swimming pools.

Plus, the transparent lid not only provides a secure stand for the Pocket Tester in daily use, but also makes it easier to maintain the electrodes. A three-colour LED lighting system - blue, green and red - and new display icons make the tester easy to use and intuitive to operate. The use of energy saving LEDs and 4 x AAA batteries greatly extends the life of the new Pocket Tester range to up to 2000 hours.

With the included lanyard, each SD Series tester can be worn comfortably around the neck or attached to a pocket, waistband or belt with the clip on the head of the tester, allowing it to be taken anywhere without tiring the hands.

Measuring Range

Test Name	Measuring Range
ORP	-1000 - 1000 mV
Temperature	0 - 50 °C

Technical Data

Accuracy	mV: ± 0.2 % FS Temperature: ± 0.5 °C
Display	3 coloured backlit LCD (blue: measurement, green: calibration, red: alarm)
Auto – OFF	No
Calibration	1 point calibration with ± 150 mV adjustable ORP value
Power Supply	4 micro batteries (AAA)
Battery Life Time	> 2000 h
Portability	Portable
Temperature Compensation	Automatically
Resolution	ORP: 1 mV
Resolution Temperature	0.1 °C
Calibration Points	1
Buffer Auto Recognition	+ 470 mV (25 °C), Pt Ag/AgCl (3 M KCl)
Calibration Indicator	No
Stability Indicator	Yes
Auto-Hold Function	Yes
Alarm Limits	Yes
Environmental Conditions	0 - 60 °C / 0 - 80% rel. humidity (non-condensing)
Protection Class	IP 67

Compliance	CE
Dimensions	40 x 40 x 180 mm
Weight	151 g
Weight with Packaging	268 g

Delivery Scope

- ☐ Tester incl. electrode
- ☐ 4 AAA batteries
- ☐ Lanyard
- ☐ Storage box
- ☐ 3 M KCl Storage Solution for pH/ORP
- ☐ Multilingual instruction manual
- ☐ Certificate of compliance
- ☐ Warranty declaration

Title	Part Number
Micro batteries (AAA), set of 4	1950026
Redox calibration solution, 470 mV, 100 ml	195070
Measuring beaker, 100 ml	384801
Deionised Water	461275
Replacement electrode for SD20 ORP	720025
3 M KCl Storage Solution for pH/ORP, 25 ml	726402
3 M KCl Storage Solution for pH/ORP, 100 ml	726404

Tintometer GmbH

Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
sales@lovibond.com
www.lovibond.com
Germany

The Tintometer Limited

Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
sales@lovibond.uk
www.lovibond.com
UK

Tintometer China

9F, SOHO II C.
No.9 Guanghualu,
Chaoyang District,
Beijing, 100020
Customer Care China Tel.: +86 021
69910081
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Tintometer South East Asia

Unit B-3-12, BBT One Boulevard,
Lebuh Nilam 2, Bandar Bukit Tinggi,
Klang, 41200, Selangor D.E
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malaysia

Tintometer Brazil

Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@lovibond.us
www.lovibond.com.br
Brazil

Tintometer Inc.

6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@lovibond.us
www.lovibond.us
USA

Tintometer India Pvt. Ltd.

Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@lovibond.in
www.lovibondwater.in
India

Tintometer Spain

Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Spain