



PRODUCT NUMBER: 4580081
DEXPURE 800-81

Honeywell

Overview

Reference Number

4580081

Product Type

Gloves

Range

Chemical Protection

Line

Disposable

Brand

Honeywell

Brand formerly known as

SPERIAN

Industry

- Automotive and Part Manufacturer
- Industrial Cleaning
- Printing Industries
- Aviation
- Laboratory
- Maintenance
- Catering
- Medical and Pharmaceutical
- Chemical Industries
- Petro-chemical
- Food Industries

Product Use

Agrifood industry: final phase of the processing of fish, meat and poultry, dairy products, cheese, biscuits, collective catering. Medical laboratories. Fine assembly of oily parts. For the handling of chemicals. Electronics.

Features & Benefits

Feature

Unpowdered nitrile disposable glove. Blue translucent. Length : 24-26 cm. **AQL : 1,5**

Benefit

Comfort: Disposable glove for an excellent touch. Its patterned finish provides a better grip.

Resistance: Nitrile offers better mechanical resistance than latex. It also provides superior performance when in contact with greasy products.

Hygiene: The glove is treated to prevent the development of bacteria. Its non-powdered interior ensures the absence of a transfer of cornstarch to foodstuffs, for a lower risk of allergy.

Certified for contact with food. Its blue colour easy to detect makes it suitable for the agrifood industry.

Nitrile is an alternative for users who are allergic to natural latex.

Technical Description

Description

CE CATEGORY : III Irreversible or lethal risks

In accordance with standards:

EN 420:2003+A1:2019 – Basic requirements

EN ISO 374-1:2016 / A1:2018 – Type C – Chemical hazards

EN ISO 374-5:2016 – Microorganisms

EN 455 - Medical gloves for single use

Regulation (EC) 1935/2004 – Food contact

EN ISO 374-1 Resistance to permeation by chemicals

Type C

Tested chemicals :

- Sodium hydroxide 40% (K)
- Formaldehyde 37% (T)

Characteristics

Unpowdered disposable nitrile glove. Blue translucent.

Product Technology

Dipped Gloves

Length

24-26 cm

Thickness

0.1mm

Harmlessness

In conformity with the European standards.

Dexterity

Class 5

Certifications

EC PPE Category

3

EC Certificate Number

0075/797/162/03/19/0985 EXT 01/03/19

Additional Information

User Manual

UI 244

Maintenance

Storage Information

Minimum packaging : 1 box of 100 gloves.

Cartons of 10 boxes.

Instructions for use printed on the box.

Care Instructions

In order to keep its properties, this article should not be cleaned.